

# ROPER RHODES®

Scheme / System Wall Mounted Furniture Handle Templates

1. Fold the dotted line at the top of this template over the top of the drawer front. Using the centre line at the top of the page, ensure the template is central to the drawer front. Tape into place.

2. Locate the handle template holes which correspond with the chosen handles. **Please note** - not all handles are suitable for System due to the curved front.

3. Carefully clamp a piece of wood to the back of the drawer being careful not to mark / damage the surface.

4. Drill through the front of the drawer ensuring the drill bit goes through to the wood behind.

5. Screw the handles onto the drawer front from behind.

For top drawer handles, use line below for drilling handle holes



For bottom drawer handles, use line below for drilling handle holes



- (SCHH04B/C.492) - 492mm
- (SCHH02C.384) - 384mm
- (SCHH03C.352) - 352mm
- (SCHH04B/C.320) - 320mm
- (SCHH01C.256 & SCHH02C.256) - 256mm
- (SCHH07C.240) - 240mm
- (SCHH08C.224) - 224mm
- (SCHH06C.192) - 192mm
- (SCHH01C.160) - 160mm
- (SCHH08C.128) - 128mm
- (SCHH08C.128) - 128mm
- (SCHH01C.160) - 160mm
- (SCHH06C.192) - 192mm
- (SCHH08C.224) - 224mm
- (SCHH07C.240) - 240mm
- (SCHH01C.256 & SCHH02C.256) - 256mm
- (SCHH04B/C.320) - 320mm
- (SCHH03C.352) - 352mm
- (SCHH02C.384) - 384mm
- (SCHH04B/C.492) - 492mm