

IMPORTANT - Read before installation

- Before fitting, ensure that there is no damage to the product and there are no missing parts.
- We strongly recommend the use of a qualified plumber throughout the installation.
- Flush out all impurities and debris from cistern and pipe work prior to installation.
- Check all flush and inlet valves in the cistern before installation, checking that both are securely assembled.
- Periodic cleaning and maintenance should be used to avoid formation of damaging lime scale deposits. Aggressive cleaning agents may damage some materials such as the seat hinges and other plastic components. Only clean with warm soapy water.
- Do not introduce caustic chemical substances into the cistern. These can damage the valve components and cause product failure.
- Take care using power tools – The use of a residual current device (RCD) is recommended. Beware of hidden cables or pipes when drilling.

INSTALLATION INSTRUCTIONS

1. Install inlet valve and flush valve inside the cistern, please follow manufacturer's instructions provided with the flush fittings. Ensure rubber seals are sealed well inside the tank. Hand tighten then a quarter turn past hand tight with a wrench (do not overtighten). It is recommended that the inlet valve is connected to the supply using a flexible hose to facilitate installation. Wrap the thread in PTFE tape. Do not overtighten the supply to the inlet valve as this could damage the inlet valve causing leaks.

Fit the gasket around the flush valve outlet on the underside of the cistern. When fitting the cistern to the pan take care to ensure the gasket is properly aligned in its location. Failing to do so could result in leaks.

Insert the cistern fitting bolts arranging the components as shown in the diagram. Connect the tank to the pan by firmly tightening the nuts and wing nuts, taking care not to overtighten as this could damage the ceramic.

2. Install the floor and wall brackets as shown right. It is highly recommended to measure your actual product first in case of differences due to manufacturing tolerances.

Connect the water supply to the cistern using a flexi hose and approved double check valve to fluid category 3 in addition to an accessible service valve. Connect a suitable waste connector to the outlet of the pan. It is recommended to use a flexible pan waste connector that utilises a jubilee clip arrangement. Once supply and soil connections are established, check that they are properly connected before flush testing the pan and checking for any leaks.

Once all connections are satisfactory, push the pan back to the wall, ensuring that the holes align with the fixing brackets on the floor.

